

Modello	1100-4	1102-4	1106-4	1108-4	1112-4	1114-4	1118-4	1120-4
Type	1200-6	1202-6	1206-6	1208-6	1212-6	1214-6	1218-6	1220-6
Modèle	1300-7	1302-7	1306-7	1308-7	1312-7	1314-7	1318-7	1320-7
Modell	1400-10	1402-10	1406-10	1408-10	1412-10	1414-10	1418-10	1420-10
Modello	1600-4	1602-4	1606-4	1608-4	1612-4	1614-4	1618-4	1620-4
Type	1700-6	1702-6	1706-6	1708-6	1712-6	1714-6	1718-6	1720-6
Modèle	1800-7	1802-7	1806-7	1808-7	1812-7	1814-7	1818-7	1820-7
Modell	1900-10	1902-10	1906-10	1908-10	1912-10	1914-10	1918-10	1920-10

Electroventilatori Ventilateurs	Fans Ventilatoren	Ø 450/500 mm x n°			
		1	2	3	4
A	mm	1285	2085	2885	3685
B	mm	830	1630	2430	1600
C	mm	---	---	---	1630

Usare valvola termostatica con equalizzatore esterno.

Use externally equalized thermostatic expansion valve.

Employer un détendeur avec égalisateur de pression externe.

Thermostatische Expansionsventile mit äußerem Druckausgleich sind zu verwenden.

