

Modello	Type	BMA - SMA	211	212	213	214	221	222	231	232	241	242
Modèle	Modell	BMA - SMA	311	312	313	314	321	322	331	332	341	342
Elettroventilatori Ventilateurs	Fans Ventilatoren	\varnothing 300 mm	n°	1	1	1	1	2	2	3	3	4
Attacchi	entrées	BMA	12	12	12	12	12	16	16	16	16	22
Connection	Entritt	SMA	12	12	12	12	12	12	12	12	12	16
Raccordi	uscita	BMA - SMA	16	18	18	18	18	28	28	28	28	35
Anschlüsse	sortie											
Dimensioni	Dimensions	A	792	792	1137	1137	1347	1347	1902	1902	2457	2457
Dimensions	Abmessungen	B	593	593	938	938	1148	1148	1703	1703	2258	2258

Usare valvola termostatica con equalizzatore esterno.

Use externally equalized thermostatic expansion valve.

Employer un détendeur avec égalisateur de pression externe.

Thermostatische Expansionsventile mit äußerem Druckausgleich sind zu verwenden.

