

Modello	Type	BMA - SMA	211	212	213	214	221	222	231	232	241	242
Modèle	Modell	BMA - SMA	311	312	313	314	321	322	331	332	341	342
Elettroventilatori Ventilateurs	Fans Ventilatoren	\varnothing 300 mm	n°	1	1	1	1	2	2	3	3	4
Attacchi	entrées	BMA	12	12	12	12	12	16	16	16	16	22
Connection	Entritt	SMA	12	12	12	12	12	12	12	12	12	16
Raccordi	uscita	BMA - SMA	16	18	18	18	18	28	28	28	28	35
Anschlüsse	sortie											
Dimensioni	Dimensions	A	792	792	1137	1137	1347	1347	1902	1902	2457	2457
Dimensionen	Abmessungen	B	593	593	938	938	1148	1148	1703	1703	2258	2258

Useare valvola termostatica con equaliz-
zatore esterno. Use externally equalized thermostatic
expansion valve. Employer un détendeur avec égalisateur
de pression externe. Thermostatische Expansionsventile mit
äußerem Druckausgleich sind zu
verwenden.

